Annex E

Event and Action Plans

 Table 1
 Event/Action Plan for Construction Noise

Event	Action							
	ETL	IEC	FSR	Contractor				
Action Level	1. Notify the IEC and Contractor	1. Review the analysed results	1. Confirm the receipt of notification	1. Submit noise mitigation				
	2. Carry out investigation	submitted by the ET	of failure in writing	proposals to IEC				
	3. Report the results of investigation to	2. Review the proposed remedial	2. Notify the Contractor	2. Implement noise mitigation				
	the IEC and the Contractor	measures by the Contractor and advise	3. Require the Contractor to propose	proposals				
	4. Discuss with the Contractor and	the FSR accordingly	remedial measures for the analysed					
	formulate remedial measures	3. Supervise the implementation of	noise problem					
	5. Consider undertaking ad hoc	remedial measures	4. Ensure remedial measures are					
	monitoring to check mitigation		properly implemented					
	effectiveness							

Note: ETL – Environmental Team Leader, IEC – Independent Environmental Checker, FSR – Franchisee's Site Representative

Table 2 Event/Action Plan for Water Quality

EVENT	ACTION										
T A FIA I	ETL	IEC	FSR	Contractor							
Action Level being exceeded by one sampling day	 Repeat <i>in-situ</i> measurement to confirm findings; Identify source(s) of impact; Inform the IEC and the Contractor and FSR; Check monitoring data, all plant, equipment and the Contractor's working methods; Discuss mitigation measures with the IEC and the Contractor; 	 Discuss with the ET and the Contractor on the mitigation measures; Review proposals on mitigation measures submitted by the Contractor and advise the FSR accordingly; Assess the effectiveness of the implemented mitigation measures. 	 Discuss with the IEC on the proposed mitigation measures; Make agreement on the mitigation measures to be implemented. 	 Inform the FSR and confirm notification of the non-compliance in writing; Rectify unacceptable practice; Check all plant and equipment; Consider changes of working methods; Discuss with the ET and the IEC and propose mitigation measures to the IEC and the FSR; Implement the agreed mitigation measures. 							
Action Level being exceeded by more than one consecutive sampling days	 Repeat <i>in-situ</i> measurement to confirm findings; Identify source(s) of impact; Inform the IEC and the Contractor and FSR; Check monitoring data, all plant, equipment and Contractor's working methods; Discuss mitigation measures with the IEC and the Contractor; Ensure mitigation measures are implemented; 	 Discuss with the ET and the Contractor on the mitigation measures; Review proposals on mitigation measures submitted by the Contractor and advise the FSR accordingly; Assess the effectiveness of the implemented mitigation measures. 	 Discuss with the IEC on the proposed mitigation measures; Make agreement on the mitigation measures to be implemented; Assess effectiveness of the implemented mitigation measures; 	 Inform the FSR and confirm notification of the non-compliance in writing; Rectify unacceptable practice; Check all plant and equipment; Consider changes of working methods; Discuss with the ET and the IEC and propose mitigation measures to the IEC and FSR within 3 working days; Implement the agreed mitigation measures. 							

EVENT	ACTION											
T A DIAI	ETL	IEC	FSR	Contractor								
Limit Level being exceeded by one consecutive sampling day	 Repeat <i>in-situ</i> measurement to confirm findings; Identify source(s) of impact; Inform the IEC, the Contractor and the DEP; Check monitoring data, all plant, equipment and the Contractor's working methods; Discuss mitigation measures with the IEC, the FSR and the Contractor; Ensure mitigation measures are implemented; 	 Discuss with the ET / Contractor on the mitigation measures; Review proposals on mitigation measures submitted by the Contractor and advise the FSR accordingly; Assess the effectiveness of the implemented mitigation measures. 	 Discuss with the IEC, the ET and the Contractor on the proposed mitigation measures; Request the Contractor to critically review the working methods; Make agreement on the mitigation measures to be implemented; Assess the effectiveness of the implemented mitigation measures. 	 Inform the Engineer and confirm notification of the non-compliance in writing; Rectify unacceptable practice; Check all plant and equipment; Consider changes of working methods; Discuss with the ET, the IEC and the FSR and propose mitigation measures to the IEC and the FSR within 3 working days; Implement the agreed mitigation measures. 								
Limit Level being exceeded by more than one consecutive sampling days	 Repeat <i>in-situ</i> measurement to confirm findings; Identify source(s) of impact; Inform the IEC, the Contractor and DEP; Check monitoring data, all plant, equipment and Contractor's working methods; Discuss mitigation measures with the IEC, the FSR and the Contractor; Ensure mitigation measures are implemented; 	 Discuss with ET and Contractor on the mitigation measures; Review proposals on mitigation measures submitted by the Contractor and advise the FSR accordingly; Assess the effectiveness of the implemented mitigation measures. 	 Discuss with the IEC, the ET and the Contractor on the proposed mitigation measures; Request Contractor to critically review working methods; Make agreement on the mitigation measures to be implemented; Assess effectiveness of the implemented mitigation measures; Consider and instruct, if necessary, the Contractor to slow down or to stop all or part of the marine work until no exceedance of Limit Level. 	 Inform the FSR and confirm notification of the non-compliance in writing; Rectify unacceptable practice; Check all plant and equipment; Consider changes of working methods; Discuss with the ET, the IEC and the FSR and propose mitigation measures to the IEC and the FSR within 3 working days; Implement the agreed mitigation measures; As directed by the FSR, slow down or stop all or part of the construction activities. 								

Table 3Action Plan for Dolphin Monitoring

EVENT	A	TION						
	ET	ΓL	IE	С	FS	R	Co	ntractor
Dolphin numbers recorded in the post-construction monitoring are significantly lower than those	1.	Repeat statistical data analysis to confirm findings; Review historical data to	1.	Discuss monitoring with the ETL and the Contractor; Review proposals for repeat	1.	Discuss the repeat monitoring and any other measures proposed by the ETL with the	1.	Inform the FSR and confirm notification of the non-compliance in writing;
recorded in the pre-construction monitoring		ensure differences are as a result of natural variation or previously observed seasonal differences;		monitoring and any other measures submitted by the Contractor and advise the FSR accordingly;	2.	IEC; Make agreement on the measures to be implemented.	2.	Discuss with the ETL and the IEC and propose measures to the IEC and the FSR; Implement the agreed
	3.	Identify source(s) of impact;					٥.	measures.
	4.	Inform the IEC, FSR and Contractor;						
	5.	Check monitoring data, all plant, equipment and Contractor's working methods;						
	6.	Discuss mitigation measures, such as additional dolphin monitoring, with the IEC and Contractor.						

Note: ETL – Environmental Team Leader, IEC – Independent Environment Checker, FSR – Franchisee's Site Representative

Table 4 Action Plan for Cultural Heritage, Landscape and Visual Resources

Action Level	ETL ⁽¹⁾	IEC(1)	FSR ⁽¹⁾	Contractor ⁽¹⁾		
Non-conformity on one occasion	 Identify Source Inform the Contractor, IEC and the FSR 	 Check report Check the Contractor's working method 	 Notify Contractor Ensure remedial measures are properly implemented 	 Amend working methods Rectify damage and undertake any necessary replacement 		
	3. Discuss remedial actions with the IEC, the FSR and the Contractor4. Monitor remedial actions until rectification has been completed	3. Discuss with the ETL and the Contractor on possible remedial measures4. Advise the FSR on effectiveness of proposed remedial measures.				
		5. Check implementation of remedial measures.				
Repeated Non- conformity	 Identify Source Inform the Contractor, IEC and 	1. Check monitoring report	 Notify the Contractor Ensure remedial measures are properly implemented 	 Amend working methods Rectify damage and undertain 		
	the FSR 3. Increase monitoring frequency	Check the Contractor's working method		any necessary replacement		
	4. Discuss remedial actions with the IEC, the FSR and the Contractor	3. Discuss with the ETL and the Contractor on possible remedial measures				
	5. Monitor remedial actions until rectification has been completed	4. Advise the FSR on effectiveness of proposed remedial measures				
	6. If exceedance stops, cease additional monitoring	5. Supervise implementation of remedial measures.				

Note: (1) ETL – Environmental Team Leader, IEC – Independent Environmental Checker, FSR – Franchisee's Site Representative